Isolation and Endplates / Cross Connection Systems

F9622 = Product group; Product group discount F 96 2_

PTR Isolation and Endplates

For DIN-Rail Terminals Series: TW, AP

Features

In general end plates are used at the end of each terminal row. If different terminals of different sizes are used on 1 terminal row, end plates are also used between these different sized terminals. The overall dimension of end plates conform to the dimension of the terminal to match. When operating with cross-connections partition plates have to be mounted between the cross-connection. This is necessary in order to follow the prescribed air and creepage distances.

Technical Specifications


- For SR2.5, SR4
- Colour: beige


Terms of Delivery

Minimum order quantity: 1 PKU = 5 pieces

http://www.ptr-messtechnik.de

Part Nr.	Part description	
TW2.5-10	Isolation Partition Beige	
AP2.5-10	End Plate Beige	





AP2.5-10

F9625 = Product group; Product group discount F 96 2_

PTR Cross Connection Systems For DIN-Rail Terminals

Series: Q

Features

- · Connection sleeve and fixing screw are already captively
- . For DIN-Rail Terminals with width of 5mm
- Continuous current of 20A
- Available in 2-, 3-, 4- und 10-pole

Terms of Delivery

Minimum order quantity: 1 PKU = 5 pieces

QVB4: 1 PKU = 2 pieces QVB10: 1 PKU = 1 piece

Manufacturer: ... MINITERNITE

http://www.ptr-messtechnik.de

Part Nr.	Part description
QVB2	Cross Connection Systems 2pole
QVB3	Cross Connection Systems 3pole
QVB4	Cross Connection Systems 4pole
QVB10	Cross Connection Systems 10pole

