

HITPOINT

NO.4, Lane 505, Zhongzheng Rd, Linkou shiang Taipei, Taiwan 24445 .R. O. C


Piezo Electric Sounder


PT-1640ML-03Q

DATE:2013.9.16
VER 0
4.0 ±0.5
1-25
3
3 at Rated Voltage
75at 10cm at 4KHz
14,000 ± 30 at 1K Hz
-30 ~ +100
-40 ~ +110
250 ± 5 \sim / within5sec
350±20 ~ / within 5sec

PS Vp-p 1/2duty, square wave

2 Typical Frequency Response Curve





3-2 Material

Housing	LCP plastic resin (Color : Black)
Weight (Gram)	1

HITPOINT



FAX:8862-26013898

NO.4, Lane 505, Zhongzheng Rd, Linkou shiang Taipei, Taiwan 24445 .R. O. C


4. TESTING METHOD

. Standard Measurement conditions

Temperature:25±2℃ Humidity:45-60%

. Acoustic Characteristics

The oscillation frequency, current consumption and sound pressure are measured by the measuring instruments shown below.



5. RELIABILITY

ITEMS	METHOD OF TEST AND MEASUREMENTS	PERFORMANCE
Coldness	After 98 hours of being exposed to -30 $^{\circ}$ C environment,	No abnormality
withstanding	should be returned to normal environment for 2 hours,	shall exist
	then re-proceed to test.	
Hotness	After 98 hours of being exposed to +110℃	No abnormality
withstanding	environment, should be returned to normal	shall exist
	environment for 2 hours, then re-proceed to test.	
Humidity	After 98 hours of being exposed to 40°C 95%RH	No abnormality
withstanding	environment in actual operation, should be returned to	shall exist
	normal environment for 2 hours, then re-proceed to	
	test.	
Durability	Testing after 98 hours actual continuous operation. (at	No abnormality
	standard measurement conditions)	shall exist
Drop	A natural drop from 75cm high down to the ground.	No abnormality
withstanding		shall exist
Vibration	Vibration of 2,000 cycles per minute, 2mm amplitude,	No abnormality
withstanding	applied in X, Y and Z directions for	shall exist
	30 minutes each.	



6. PACKAGE METHOD

- < 1 >800pcs per tape reel; 8ape reel per carton , total 6400pcs carton; Volume: L*W*H=520*335*290mm
- < 2 >N W 8KGS G W 9KGS
- < 3 > RoHS Mark

